

#### 4 – канальный режим (2)

Канал	Функция	Описание
CH1	Total Dimmer	WW/ CW Total Dimmer- Dark to Bright
CH2	Total Strobe	Total Flash Strobe, Slow to Fast
CH3	Function Choice	000~050: CH1-CH6 Control. 051~100: jump effect 101~150: Gradate 151~200: Pulse Change. 201~255: Sound-Active
CH4	Function/Speed	Slow to Fast

#### 2 – канальный режим

Канал	Функция	Описание
CH1	Total Dimmer	WW/ CW Total Dimmer- Dark to Bright
CH2	Total Strobe	Total Flash Strobe, Slow to Fast

#### 2 – канальный режим (2)

Канал	Функция	Описание
CH1	WW Dimmer	Warm white - Dark to Bright
CH2	CW Dimmer	Cool white Dimmer- Dark to Bright

### 3. Технические характеристики:

Мощность – 230 Ватт

Источник света – 200-Ваттный светодиод (тёплый белый, холодный белый, 2 в1)

Угол раскрытия луча- 60 градусов

Режимы работы – Auto, Sound, DMX512, Master-slave

DMX каналы – 2/4/6 – канал0ьные рабочие режимы

Размеры – 320x240x220 мм

Вес – 3 кг.



## PL PAR 200W COB



## Паспорт прибора

## 1. Функции:

№	Меню	Значение	Функции
1	A001	001- 512	DMX512 add setting, UP/ DOWN increase or reduce the value
2	A/b2CH A/b4CH A/b6CH		6kind of DMX Working mode
3	CC99	01-99	Colors Jump, UP/ DOWN increase or reduce the value
4	CP99	01-99	Colors Gradate, UP/ DOWN increase or reduce the value
5	DE99	01-99	Colors Pulse, UP/ DOWN increase or reduce the value
6	BEBE		Sound active
7	Y255	0-255	Warm white brightness 0-100%
8	W255	0-255	Warm white brightness 0-100%
9.	-on/oFF		led display, on/off

## 2. DMX каналы:

### 6 – канальный DMX режим

Канал	Функция	Описание
CH1	Total Dimmer	WW/ CW Total Dimmer- Dark to Bright
CH2	Function/ Speed	Slow to Fast
CH3	Function Choice	000~050: CH1-CH6 Control. 051~100: jump effect 101~150: Gradate 151~200: Pulse Change. 201~255: Sound-Active
CH4	Function/Speed	Slow to Fast
CH5	WW Dimmer	Warm white - Dark to Bright
CH6	CW Dimmer	Cool white Dimmer- Dark to Bright

### 6 – канальный режим (2)

Канал	Функция	Описание
CH1	Total Dimmer	WW/ CW Total Dimmer- Dark to Bright
CH2	WW Dimmer	Warm white - Dark to Bright
CH3	CW Dimmer	Cool white Dimmer- Dark to Bright
CH4	Total Strobe	Total Flash Strobe, Slow to Fast
CH5	Function Choice	000~050: CH1-CH6 Control. 051~100: jump effect 101~150: Gradate 151~200: Pulse Change. 201~255: Sound-Active
CH6	Function/Speed	Slow to Fast

### 4 – канальный режим

Канал	Функция	Описание
CH1	Total Dimmer	WW/ CW Total Dimmer- Dark to Bright
CH2	WW Dimmer	Warm white - Dark to Bright
CH3	CW Dimmer	Cool white Dimmer- Dark to Bright
CH4	Total Strobe	Total Flash Strobe, Slow to Fast

**Гарантия на прибор составляет 12 месяцев со дня покупки**

**Дата продажи.....**

**proton.ru**

**EAC**